


MANUAL HEIGHT ADJUSTABLE HEAVY DUTY AV TROLLEY

Heavy Duty Mobile Cart for Extra Large TV or Smart Board and
Video Conference Room Solution






AR-TR-65110-145

VESA Compatible
From 200x200
up to 1000x600

110"
MAX

145kg
RATED




AR-TR-65110-145



Load capacity
145 kg

DVD Shelf loading
10 kg







TV size
65" - 110"











Height adjustment
1305mm to 1765mm






VESA Standard
200x200 up to 1000x600





1 Base Installation





2



3 Column Installation




④




ATTENTION! In order to avoid accidents, two people should participate in the installation and adjustment of the TV/touchscreen panel.





⑤


Height Adjustment






6 Shelf Bracket Assembly





OO x1	PP x1	I2 x1	D1 x4
		 S5	 M6x10




7




8 VESA Panel Mounting




C1



EE x1




H2 x1






C1 x8







9 Measure VESA Spacing









10 Suitable Screws




11 Spacer Selection



12 VESA Hole Spacing



13 Arm Installation





A2 x4	B2 x4	C2 x4	D2 x4	E2 x4
M8x25	M8x15	M6x25	M6x15	M10x15

H2 x1	F2 x4	G2 x4
S6	15x8.2x10	


AA x2

! ATTENTION! All screws must be securely tightened.
DO NOT OVERTIGHTEN THEM!






14 Screen Installation



ATTENTION! In order to avoid accidents, two people should participate in the installation and adjustment of the TV/touchscreen panel.





15




Align the screen to the centre of the VESA plate

16





! Align the screen to the centre of the VESA plate

17





! **ATTENTION!** In order to avoid accidents, two people should participate in the installation and adjustment of the TV/touchscreen panel.


19 Assembling Camera Shelf



20 Installing Camera Shelf



21 Cable Management & Castor Function



OPERATING INSTRUCTIONS.

OPERATION AND STORAGE REQUIREMENTS:

- The air temperature during storage and operation should be from +5°C to +40°C., humidity in the room should not exceed 80% and free of aggressive impurities (acid vapours, alkalis, other chemically active substances) which may cause corrosion.
- Direct sunlight exposure to the elements of the product is not allowed. Avoid dust, dirt, shock, moisture, fire and mechanical damage.
- It is best to not place the product closer than 1m to heating elements, as well as near an open fire
- The product must be placed on a flat, horizontal surface with all the wheels in the locked position.
- Dragging the trolley in locked position may cause mechanical damage.
- Do not allow children to unlock the wheels, as we as perform any other manipulations with the product. Do not allow children to play near the product.
- Do not push, pull or hang on the product with the screen as it may fall. Do not allow children to hang or swing the product with the screen. The product with screen installed may tip over and cause serious and even fatal injuries.
- Do not exert excessive force on the elements of the product, do not stand with your feet on the base of the product. If you notice any malfunction, you should immediately contact our customer service team.

OPERATING INSTRUCTIONS.

MAINTENANCE:

Dry or wet cleaning should be carried out using only neutral detergents. Avoid using abrasive detergents and sharp objects. Avoid moving on dusty, sandy surfaces and puddles.

WARRANTY:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for major failure and for compensation for any reasonably foreseeable loss or damage. You are entitled to have the goods repaired or replaced if the goods fail to be acceptable quality and the failure does not amount to a major failure (defective goods). Arkin will repair or replace such defective goods for up to 5 years from the date of purchase. This warranty is against defects in the goods purchased and does not cover damage caused by the incorrect use or installation of the goods, or by modifications, or by accident. To claim under the warranty you need to return the product to the place of purchase (at your expense) with a valid proof of purchase. If you are not able to return the product to the place of purchase you can contact Arkin via info@arkin.com.au

ARKIN

www.arkin.com.au

info@arkin.com.au

We reserve the right to modify or alter instructions.
No modification or alteration without formal notice.